

FISR SUPPLIER EDITION

Installation Guide

Author:	Product Management
Doc. No:	TECHDOK 09-2015
Doc. Name:	install3.docx
Storage Location:	\\pdc\Kunden\Harting_Electric_Espelkamp\Customer_Management\Projekte\Projektarbeit\Prj.AB112774.EMPB-Supplier-Edition\Software\EMPB-Dokumentation\Installation_EMPB_SupplierEdition_engl.docx

Böhme & Weihs Systemtechnik GmbH & Co.KG
Engelsfeld 9
45549 Sprockhövel
Phone +49 2339 9182-0
Fax +49 2339 9182-99

Böhme & Weihs Systemtechnik GmbH & Co.KG
Gartenstraße 115
73430 Aalen
Phone +49 7361 9291-0
Fax +49 7361 9291-44

© Böhme & Weihs Systemtechnik GmbH & Co.KG.

Rights including the copyright of the software programs and printed materials (manuals and other documents) rest with Böhme & Weihs Systemtechnik GmbH & Co.KG. The specifications in the following document may be modified without prompting a special note. By publishing this document, Böhme & Weihs does not enter into any commitment. Having lawfully purchased the software licenses and manuals, you are allowed to use the program according to the number of licenses purchased. Limited warranty: the document is provided without any warranty as to its correctness or accuracy of statement. In spite of all efforts, there may still be omissions or errors. Delivery of standards: standards made available on the delivery of the software do not include the eventually necessary licensing of these standards. This must be arranged by the company using the product.

Version	Changes in Comparison to Previous Version / Slide	Date	Done by
1.0	Creation	25/09/15	PM
1,1	Amendment	22/10/15	PM

Table of Contents

1	General.....	5
2	Installation Requirements.....	5
3	Installation Process.....	6

1 General

The PPAP Supplier Edition is installed on the client computer.

2 Installation Requirements

Compatible Operating Systems:


MS Windows 7 Professional (32/64-bit), IE 9 ff

MS Windows 8.x Pro (32/64-Bit), IE 10 ff


	<u>Minimum Requirement</u>	<u>Recommended System Configuration</u>
Processor:	Intel Core i3 (or comparable)	Intel Core i5 (or comparable)
RAM:	4 GB RAM	8 GB RAM
Free Hard Disk Space:	20 GB	20 GB
Network Card:	1000 MBit	1000 MBit
Drive (Optional):	DVD	DVD
Screen Resolution	1.280 x 1.024 Pixel	1.920 x 1.080 Pixel

3 Installation Process


Select the desired language.



Afterwards click **Next >**.




The InstallShieldWizard for EMPB Supplier Edition will be displayed.
Afterwards click **Next >**.




Specify the desired target path.

If you want to change the default path, select **Browse**.




Select the target path, and then click **Next >**.



Select the program folder.

Click **Next >**.



Select **Finish**.

The Supplier Edition icon will be stored to the desktop.



Open the program by double-click.

